



Pet Fountain USER MANUAL

Please read the user manual carefully before using the product

Checking the product is intact or not when you received it.
Please check with the list to confirm that accessories are complete.



Product Diagram




Three levels of water outlet are available to choose from



Tips

1. It is recommended to replace the filter every 15 days.
2. It is recommended to replace the water pump filter sponge every 15 days.
3. It is recommended to clean the water tank every 7 days.
4. When cleaning the water tank, do not soak in water.

Instruction



Installation Video



Scan the QR code on the left to watch product assembly and product showcase videos